



IP Set Instructions

The IP SET program is designed to help you integrate your device into your network. It is meant to help simplify the set up procedure, specifically the network configuration.

Before executing the IPSET.exe file, ensure that the device is connected to the same LAN as the workstation you are executing the program. There may be information you have to obtain from your system administrator to complete the requirements of the IP SET program. Once opened, IP SET will detect the NIC and IP address of the workstation it is run from. Please fill in the following "Target" information:

Target

IP Address: An IP address on your network that is not currently in use, that you would like to designate as the IP address of the device.

Subnet: The subnet that the device will use when installed.

Default: The Default Gateway the device will use when installed.

MAC Address: All MAC addresses for these devices are prefaced with 00-08-67. Please fill in the last three octets of the MAC address. The full MAC address is located on a sticker on the bottom of the unit.

Status: After filling out the information click "Apply". This box will show you the results of the execution.

If the status screen displays, "No response from target." then you may have entered the information incorrectly or the information may have been set correctly but is not viewable on the current network. If this is the case, review the network information or move the device to the network of its final destination.

Any questions or concerns arising from this procedure should be directed to the BayTech support team at:

support@baytech.net

Bay Technical Associates
200 North Second Street
Bay St. Louis, MS 39520
Domestic: 800.523.2702
International: 228.467.8231