

Reset Procedures for the RPS Series

Setting the unit back to factory default will lose all configuration of the unit.

WARNING: Before attempting a factory reset, make sure all power sources are disconnected.

RPS Configuration Reset

1. Unplug the unit from its source
2. Locate a thin rigid object such as a paperclip or toothpick
3. Locate the “reset” hole (reference picture below)
4. Insert the rigid object into the hole until you feel the button inside click down
5. With the rigid object inserted and button pressed, plug the unit in
6. Hold the rigid object with the reset button down and the unit powered on until you here a “beep” (approximately 5-7 seconds)
7. Remove the rigid object
8. Check to verify reset

Your unit’s configuration is now reset

Vertical/ZeroU RPS



Horizontal/Rackmount RPS



Any questions or concerns arising from this procedure should be directed to the BayTech support team at:

support@baytech.net

Bay Technical Associates
200 North Second Street
Bay St. Louis, MS 39520
Domestic: 800.523.2702
International: 228.467.8231