

Vertical RPC DE & N

There is a micro switch behind a small pin hole near the sensor ports.

1. Insert a paper clip; press and hold switch for 10 seconds.
2. Continue pressing switch and remove power from unit for 10 seconds.
3. Continue pressing switch and restore power to unit. There should be a short beep and the LEDs may blink off for several seconds than back on.
4. Remove the paper clip.
5. Connect to the serial port. If unit ask for a username type (root) without the brackets, press 'Enter'. For password type (baytech) without the brackets, press 'Enter'

Universal RPC login: root

Password: baytech

Password will not echo character.

Caution: any devices connected to the power strip will be affected.