

Unit Reset Instructions

The Unit Reset procedure is fairly easy and can be completed by running the executable **reset.exe**. Make sure that the device you wish to reset to factory default is on the same subnet as the workstation you are executing the program from.

There may be information you have to obtain from your system administrator to complete the requirements of the reset program. Once opened, reset.exe will ask for the following:

IP Address: The IP address that the unit currently has. If you do not know the IP run the IP Set program to give it a new IP.

Admin Password: The password of the admin account registered on the device.

Any questions or concerns arising from this procedure should be directed to the BayTech support team at:

support@baytech.net

Bay Technical Associates
200 North Second Street
Bay St. Louis, MS 39520
Domestic: 800.523.2702
International: 228.467.8231