


RPC7

To reset the unit to factory default:

1. Turn off the power to the RPC
2. Remove the lid
3. Locate JP1 on the controller board (see picture below)
4. The jumper is placed on pins 1 and 2, move it to 2 and 3
5. Turn power on for 10 seconds
6. Turn power off
7. Return jumper to its original position.

The unit will now be rest to factory default.



* The arrow in the above picture is pointing to the JP1 pin

Any questions or concerns arising from this procedure should be directed to the BayTech support team at:

support@baytech.net

Bay Technical Associates

200 North Second St.

Bay St. Louis, MS 39520

Domestic: 800.523.2702

International: 228.467.8231